

## PIPE SEALING COUPLING - 1-1/2"





1-1/2" FPT PIPE COUPLING, STAINLESS STEEL

Model C150S

\* Stainless Steel Hardware & 3M Sealant Provided

- INSTALLATION INSTRUCTIONS

  1. LOCATE PIPE OR COUPLING CENTER.

  2. CUT HOLE TO THE OUTSIDE DIAMETER OF THE COUPLING.

  3. APPLY GASKET TO COUPLING OR BASIN.

  4. PLACE COUPLING AND DRILL HOLES FOR

- BOLTS.
  5. INSERT BOLTS, WASHERS, NUTS AND TIGHTEN.



PIPE COUPLINGS Reference:	Scale: None Drawn By: RM Appv'd By: Date:	This print is and contains confidential proprietary information owned exclusively by TOPP BUSINESS, W.C. It is furnished on a strictly confidential basis. This restriction includes, but in set limited to the conditions that the print will not only only and the condition that the print will not only only only only on the condition that the print will not be used to meanfurfacture or procure the noninformation of the items bears in this print the your or other source than TOPP BUSINESS. NO.
Highway 25 North P.O. Box 420 Rochester, IN 46975 Phone: 800/354-4534 Fax: 574/223-6106	Supersedes Prints Prior To:	09-07-13